



5720 Lawton Dr Sarasota, FL 34233  
941-923-6778 Toll Free: 800-831-1231

## DO IT YOURSELF

## HURRICANE WINDOW SHUTTERS

### DIRECT MOUNT - METHOD #1

**Step 1** – Determine where you want to start with the first panel and mark a spot to drill holes (minimum of 2 ¼” away from edge of window opening).

**Step 2** – Drill holes in panel, start with a smaller bit and work up to a ½” hole.

**Step 3** – Hold panels up in the same spot as before and mark the wall in the center of the holds.

**Addition Panels:** For installs with additional panels, repeat this process but make sure when starting the additional panel, you overlap the first valley with the one that is currently installed. Additional panels will be marked with a sticker (Kitchen A, Kitchen B) to show their order.

**Step 4** – Using the hammer setting on your drill, drill holes in all areas marked. Make sure to drill deep enough to set the anchors.

**Step 5** – Using a driver, secure panel mates in all the holes drilled.

**Step 6** – Hold the panel in place and fasten with sidewalk bolts. Do not over tighten as the heads may strip out.

