



5720 Lawton Dr Sarasota, FL 34233
941-923-6778 Toll Free: 800-831-1231

DO IT YOURSELF

HURRICANE WINDOW SHUTTERS

DIRECT MOUNT - METHOD #2

Step 1 – Determine where you want to start with the first panel and mark a spot to drill holes (minimum of 2 ¼” away from edge of window opening).

Step 2 – Drill holes in panel, start with a smaller bit and work up to a ½” hole.

Step 3 – Hold panels up in the same spot as before and mark the wall in the center of the holds.

Addition Panels: For installs with additional panels, repeat this process but make sure when starting the additional panel, you overlap the first valley with the one that is currently installed. Additional panels will be marked with a sticker (Kitchen A, Kitchen B) to show their order.

Step 4 – Using the hammer setting on your drill, drill holes in all areas marked. Make sure to drill deep enough to set the anchors.

Step 5 – Using a driver, secure panel mates in all the holes drilled.

Step 6 – Take your panel and slide it onto the panel mates. (Note: you may need to make the holes in the panel slightly bigger to easily slide panels onto mounted panel mates. Fasten panel with wing-nuts and washers.

