



5720 Lawton Dr Sarasota, FL 34233  
941-923-6778 Toll Free: 800-831-1231

## DO IT YOURSELF

### HURRICANE WINDOW SHUTTERS

#### PERMANENT MOUNT - METHOD #1

Most of our tracks install the same way. If your track is being installed onto a concrete block structure, your anchors should be spaced no more than 12" apart. If you are attaching to wood, they should be no more than 6" apart.

The first thing you should do is to find the mounting section of the track. Here are a few examples:



Notice some tracks may have multiple sections to attach the anchors to. This is so you can choose which one best suits your application.

## Installation Steps

**Step 1** – Check that the track fits in place and there are no obstructions, then mark and drill appropriate sized holes for your anchor.

**Step 2** – Hold track in place and mark the wall where the hole will be drilled.

**Step 3** – Using the hammer setting on your drill and using the appropriate sized drill bit, drill the holes about 1" deeper than the anchor.

**Step 4** – Attach the track using the anchors of your choice. If they are extremely tight, try cleaning the dust out of the hole with your drill bit.

**Step 5** – Hold the panel in place after both top and bottom tracks are installed and mark where you want to drill the panel.

**Step 6** – Drill holes in panel up to 1/2" to allow enough play on the fasteners, then attach with your necessary hardware.