



5720 Lawton Dr Sarasota, FL 34233  
941-923-6778 Toll Free: 800-831-1231

## DO IT YOURSELF

### HURRICANE WINDOW SHUTTERS

#### REMOVABLE MOUNT - METHOD #2

Most of our tracks install the same way. If your track is being installed onto a concrete block structure, your anchors should be spaced no more than 12" apart. If you are attaching to wood, they should be no more than 6" apart.

The first thing you should do is to find the mounting section of the track. Here are a few examples:



Notice some tracks may have multiple sections to attach the anchors to. This is so you can choose which one best suits your application.

## Installation Steps

**Step 1** – Check that the track fits in place and there are no obstructions, then mark and drill appropriate sized holes for your anchor.

**Step 2** – Hold track in place and mark the wall where the hole will be drilled.

**Step 3** – Using the hammer setting on your drill, after determining the size and depth of hole needed, drill holes in all marked spots.

**Step 4** – insert/set anchors and check that they are tight in position. Next, drill holes in track out to 1/2" and attach using sidewalk bolts into the anchors.

**Step 5** – Hold the panel in place after both top and bottom tracks are installed and mark where you want to drill the panel.

**Step 6** – Drill holes in panel up to 1/2" to allow enough play on the fasteners, then attach with your necessary hardware.